Plasma HI VIZ

КЛЈК

FN



Technical Details

EXTERNAL SHELL: P.P. Polypropylene INTERNAL SHELL: HD Polystyrene expanded HEADBAND: Soft PA Nylon headband (fixed to the external shell without metal rivets) SIZE: Universal-adjustable from 51 to 63 cm STANDARD: EN 397 PPE CATEGORY: III





WHE00009. 201 WHITE

WHE00009.253 WHITE/GREEN WHE00009.221 YELLOW FLUO

headlamps with elastic bands on the market.

WHE00009.222 ORANGE FLUO

WHE00009.223 RED FLUO WHE00009.224 LIME FLUO

WHE00009.252 BLUE WHE00009.251 WHE BLUE/YELLOW B

WHE00009.210 BLACK

Technology



VENTILATION: Maximum ventilation thanks to the ten air intakes. The air intakes and the internal outflow channels guarantee effective breathability.

FLUORESCENT SHELL: High visibility fluorescent colour shell. Available in yellow fluo, orange fluo, red fluo, lime fluo color (the intensity of the luminescence colour will decrease in time).

LUMINESCENT CLIPS: Helmet equipped with strong nylon external luminescent lamp carrying clips, compatible with all

LUMINESCENT

FLUO



REFLECTING STICKERS: Adhesive reflecting stickers for high visibility.



R

CHINSTRAP EN 397 **ANTI-INTRUSION GRILLE:** The air intakes are equipped with an anti-intrusion grille that prevents entry of debris whilst maintaining breathability.

CHINSTRAP EN 397: Four point chinstrap fixed to the external shell without metal rivets with Quick release fastening and opening in conformity with EN 397. Provided with lateral divider for adjusting the length of the straps.

RING TO HOOK: Fitted with a special loop on the chinstrap which allows the helmet to be connected to the harness.



SANITIZED®: The Sanitized[®] treatment is an antibacterial treatment that acts as an internal deodorant counteracting the development of unpleasant odors. Thanks to its hygienic function, it effectively prevents bacterial proliferation by increasing freshness and comfort of the fabric in contact with skin.

2DRY: This high-tech and maximum comfort fabric dries very quickly, encouraging the expansion and dispersion of moisture to the outside and leaving a pleasant feeling of freshness.



2DRY

MICROMETRICAL ADJUSTMENT: The micrometrical size regulation mechanism positioned at the rear of the helmet provides quick and precise adjustment, even when wearing gloves.



VISOR ATTACHMENT: Provided with attachment for fitting visors.

EARMUFFS FITTING: Provided with bayonet socket adapter for earmuffs. Compatible with KASK earmuffs.

KASK spa - Via Firenze, 5 - 24060 Chiuduno (BG) Italy t. +39 035 4427497 - f. +39 035 4427704 - e. info@kask.it





Plasma HI VIZ

КЛЈК

EN

Performances

PROTECTION AGAINST TOP IMPACTS	K 5 Kg from 2 m 100 J
PROTECTION AGAINST SIDE, FRONT AND REAR IMPACTS	K 5 Kg from 0,5 m 25 J
PROTECTION AGAINST THE PENETRATION OF OBJECTS	K 3 Kg from 1 m 30 J
CHIN STRAP RELEASE > 15 kg <25 kg	K
RETENTION SYSTEM EFFECTIVENESS	€®*
LOWER TEMPERATURE RESISTANCE TEST	K T= -30°C
PROTECTION AGAINST SIDE DEFORMATION- LD	K
PROTECTION AGAINST MOLTEN METAL SPLASHES- MM	K



K Standard requirements

 ${\rm (I)}^{\star}$ Additional test in conformity with the requirements of the EN 12492

K Optional requirements

Additional Information



GUARANTEE

3 years starting from the purchasing date.

SHELF LIFE

10 years starting from the production date (production date is printed on a label contained on the inside of the helmet). Inspect the helmet regularly to check for any damage! Cuts, abrasions, deformation or changes in colour represent important elements for checking the helmet status.

CLEANING

Clean the helmet only with water, neutral pH soap and a soft, clean cloth. The inner lining should be washed by hand in cold water or in the washing machine (max 30°C - 85°F). Do not use chemical detergent or solvent.

STORAGE

When not in use the helmet should be stored away from direct sunlight or source of heat.

ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or intervention not provided for may impair its protective function.

Accessories



WVI00002 VISOR V2



WAC00003 ADAPTER WITH BAYONET



WVI00004 VISOR HP



WPA00002 REPLACEMENT INNER PADDING



WVI00003 VISOR FULL FACE



UAC00002 WINTER PADDING



WHP00001 EARMUFFS



KASK spa - Via Firenze, 5 - 24060 Chiuduno (BG) Italy t. +39 035 4427497 - f. +39 035 4427704 - e. info@kask.it